

Internal PC Hardware Components



Overview



Motherboards

CPUs

Add-on cards


RAM



Motherboards



Motherboards



Also referred to as “mobos”




The primary digital circuit board in a computer



Allows internal component and external peripheral connections





Motherboard form factor

- Size
- Orientation within the case

Common form factors


- ATX
- Micro ATX (mATX)
- ITX
- (Mini ITX) mITX

Connectors /slots

- Multiple CPUs
- PCI Express



Motherboard Connectors



BIOS and CMOS

BIOS/UEFI

Firmware can be updated

Firmware computer instructions

Power on password

Drive encryption

Secure boot


CMOS

BIOS/UEFIC configured settings

CMOS battery




Demo



**View motherboard details using the
CPU-Z tool**



Demo




Configure BIOS settings




CPUs



CPUs



Central Processing Unit; the “brain” of the computer




Multi-core: Multiple CPUs within a single physical chip




CPU speed is measured in Gigahertz (GHz)



Central Processing Unit (CPU)





Common CPU manufacturers

- AMD
- Intel


CPU characteristics and options

- L1, L2, L3 cache
- 32-bit vs 64-bit
- Virtualization extensions
- Overclocking
- Integrated GPU





CPU Hyperthreading





1 physical CPU




Operating System
2 logical CPUs



CPU Cooling



Demo




**View processor details using the
CPU-Z tool**




Add-on Cards




Add-on Cards



Also called “expansion cards” or simply “adapters”




Provide additional functionality to the PC



Card form factors (size, orientation)





Expansion card socket types


- PCI
- PCI Express (PCIe)
- Riser card

PCIe 3.0

- x1 means 1,000MBps bi-directionally
- x2, x4, x8, x16




PCI Express Slots




PCI Express Cards



PCI Express Power





Onboard or add-on cards


- Network interface card (NIC)
- Sound card
- Video card
- USB card
- eSATA card
- RAID controller



RAM



RAM



Random Access Memory




Volatile storage; relies on electricity



Motherboards determine the maximum possible amount of RAM





Parity

- Uses a 9th error checking bit for every byte of memory


Non-parity

- No 9th parity bit

Error correcting code

- ECC
- Not only detects but also corrects common memory corruption issues
- Often supported on non-ECC motherboards





SODIMM


- Smaller chips used in laptops

DDR RAM


- Double data rate
- Determined by the motherboard
- Does *not* have to be installed in pairs
- Many variations
- DDR2
- DDR3
- DDR4




SODIMM RAM Installation



DDR4 RAM Installation



Demo



View RAM details using the CPU-Z tool



Summary



Motherboards

CPUs

Add-on Cards

RAM

